

# smsng-cv27 VESA adapter (V2)

# **Assembly instructions**

The VESA adapter is compatible with the following Samsung products (samsung.com):

C24T550FDR, C27T550FDR, C27T550FDU, C32T550FD, C32T550FDR, LC24T550FDR, LC24T550FDU, LC27T550FDR, LC327550FDRXEN, LS27C390EAUXEN, S27C390EAU, S27C392EAN, S32C390EAU, S39C Essentials, U32J590UQP

With the VESA adapter, you can easily attach your SAMSUNG monitor to a monitor arm with a VESA hole pattern ( $75 \times 75 mm$ ). Use the supplied screws and nuts for this.

Direct wall mounting is NOT possible, as the VESA adapter already contains metric threads through which no screws can be inserted for mounting to the wall.



## **Important Safeguards**



Please read this manual carefully and keep it for future reference. If you pass the product on to third parties, this manual should always be included. Ignoring these instructions may result in injuries or damage to people and products, for which we cannot accept any liability.

#### **IMPORTANT - FOR FUTURE REFERENCE.**

- The use of this product should always be in accordance with the specified safety instructions.
- Do not install your VESA adapter in combination with the monitor in places where people are underneath.
- Do not exceed the maximum weight of the compatible monitor models, as this may result in serious injuries or property damage.
- Pay attention to the maximum ambient temperature of 35°C when using the product.
- Do not mount the VESA adapter near a heat source or in direct sunlight, as this may cause the adapter to overheat.
- Check if your mounting point (e.g., monitor arm) can support the weight of the monitor with the VESA adapter.
- The product is designed exclusively for mounting with a hole pattern of 75x75 mm.
- After installing the VESA adapter, the position of the monitor must be readjusted to ensure proper ergonomics.

#### **↑ WARNING**

Ensure that the device is turned off and disconnected from the power supply before installation to avoid possible injuries or damage.

#### 1. Before First Use

Check the product carefully for possible transport damage and for the absence of accessories, such as screws, which should be included in the scope of delivery.

#### **A** CAUTION

Make sure that packaging materials and small screws and parts contained therein are inaccessible to children to minimize the risk of choking and other risks.

### 2. Maintenance and Cleaning

#### 2.1 Maintenance

- It is recommended to check every three months that all screws are still tight. Also, regularly check the condition of all components of the product.
- Store the product in a cool and safe place, ideally at a maximum storage temperature of 40°C. For additional safety, keep the product away from children and preferably in its original packaging.
- Avoid any vibrations and shocks so as not to affect the life and functionality of the product.

#### 2.2 Cleaning

- No corrosive or hot cleaning agents should be used to clean the product. Likewise, wire brushes, metal or other sharp materials are unsuitable for cleaning and should not be used.
- For gentle and effective cleaning, the use of a soft, damp cloth is recommended.

#### 3. Waste Disposal

For the disposal of this product we recommend to contact the responsible local authorities or disposal services. They can provide you with detailed information on available disposal options and recycling centers in your area.

#### 4. Manufacturer Information

3idee S.à r.l. 19 Rue de Bitbourg L-1273 Luxembourg Luxembourg

mail: info@3idee.eu

### 5. Help and Feedback

If you need help with your article, we are here for you. We also appreciate any feedback.

https://help.3idee.eu/en/contact

# **Scope of Delivery Accessories**



**4x** M4x14 screw with cross recess (**SP2**)

# **Horizontal / Vertical Alignment**

Please note: Not all VESA adapters and monitors are designed for vertical (upright) orientation. This limitation is often due to the specific geometry of the adapter or monitor. Do not ignore this information, as the load limit of the adapter can quickly be exceeded if not installed properly.

We are continuously working on developing monitors and adapters that are also suitable for vertical orientation.

However, monitors are designed for horizontal alignment by default.





**Vertical Mounting:** No



# Video assembly instructions

## **Assembly Instruction**

#### Step 1

Remove the base of your Samsung Curved monitor.

We also recommend that you remove the round cover on the back of the monitor before you start mounting the VESA adapter and reattach it before you mount the 3idee VESA adapter.

### Step 2

Now attach the 3idee VESA adapter to your Samsung monitor as shown. (Figure 1)

**Press** the VESA adapter with**force** into the mount of the monitor

The red arrows indicate the direction in which the force must be applied.




Figure 1

### Step 3

Once you slide the VESA adapter into the back of the monitor, you may notice that the side adapter guides stick out a bit from the monitor guides. (Figure 2)

**That is correct.** The VESA adapter is correctly inserted into your Samsung monitor as shown.




Figure 2

### Step 4

▲ Important: If the instructions in this step are not suitable for your device, please follow the mounting guidelines of the manufacturer of your monitor arm or swivel arm to mount the monitor to the wall or swivel arm.

We recommend a **second person** for this step.

Now lift the monitor and hold it against your monitor mount. Attach the VESA adapter using the 4 M4x14 screws supplied (screw bag: SP2).

It is best to fasten 2 screws diagonally first so that the monitor can no longer fall down and you can fasten the remaining screws easily.




Figure 3

**ATTENTION:** Make sure you use the right screws!

(Figure 3)

### Step 5

Now please check if the monitor is correctly screwed to the monitor arm. This should look something like the picture. (Figure 4)

There is a little space at the marked position. This is correct.




Figure 4